

INSTRUCTION MANUAL

TMC MOTOR CONTROLLER 3-6 AXES

Version 2

SERIAL # _____

10.2024 231 B Otto Street - Port Townsend, WA 98368 - (360)385-7707

TMC Motor Controller 3-6 Axis

INSTRUCTION MANUAL

VERSION 2.0

TABLE OF CONTENTS

- 1 Introduction
 - 1.0 Overview
 - **1.1** Product Description
 - **1.2** Specifications
 - **1.3** System Components
- 2 System Overview
 - **2.01** TMC Controller
 - 2.011 TMC Handheld Terminal
 - 2.012 MCode Commands
 - 2.013 Terminal Software
 - 2.014 Custom Developed Software
 - 2.02 TMC Functional Diagram
- **3** Safety
 - 3.01 Personnel Safety
 - 3.02 Intended Use
- 4 Hardware Overview
 - **4.0** Mounting the TMC Chassis
 - 4.1 Handheld Terminal
 - **4.2** Rear panel Connections and Settings
 - **4.3** USB communications port
 - 4.4 I/O Connections
 - 4.5 Hardware End Limits
 - **4.6** Hardware home limit input
 - 4.61 Optical home limit (ZPI)
 - 4.62 Mechanical home limit (user supplied)
 - 4.7 Incremental Encoder Input
 - 4.8 Motor Connectors
 - **4.9** Hardware Emergency Stop
 - 4.10 AC Power Connector and Voltage Selector Switch
 - **4.11** TMC Sensor Connections
 - 4.111 Limit Switch Connections
 - 4.112 Zero Position Indicator (ZPI) Connections
 - 4.113 Encoder, Limit Switch and ZPI connections Pin Assignments
- 5 System Setup
 - 5.0 Cabling

v.2

TMC MOTOR CONTROLLER 3-6 AXES

- **5.1** Communications Setup
 - 5.11 Configuring the Communication Port
 - 5.12 Installing and configuring Terminal Software
- **6** Operation from Users Computer
 - 6.0 Controller Operation
 - 6.01 Communicating with Single Axis Systems
 - 6.02 Communicating with Two Axes Systems
 - 6.1 Hardware End Limits Settings
 - 6.2 Zero Position Indicator (ZPI) Settings
 - 6.3 MCode Programming
 - 6.4 MCode Commands
 - 6.5 Installed Programs
- 7 Hand Terminal Operation
 - **7.0** TMC Hand Terminal Function Tree (compressed view)
 - 7.1 Hand Terminal Flow Chart
 - 7.2 TMC Hand Terminal Function Tree (expanded View)

<u>Section 1: Introduction</u>

1.0 OVERVIEW

Congratulations on your selection of the Thermionics Stepping Motor Controller as your motion control solution! This unit is capable of providing many years of service with minimal care and maintenance. This manual is a tool to aid you in maximizing the potential of the TMC control system.

1.1 PRODUCT DESCRIPTION

The TMC stepping motor controller comes in various configurations. It can be supplied with 1 to 6 axes of motor control. Axes drives are available in two sizes, 3.0 or 5.0. The controller comes in a rack mount chassis. It can be operated as a stand alone unit with the optional hand held terminal or with a computer using the USB communications port.

1.2 SPECIFICATIONS

- 1 to 6 axes per chassis
- Software selectable drive current (per axis):
- 3.0 drive up to 3.0 amperes (4.2 amperes peak)

5.0 drive - up to 5.0 amperes (7.0 amperes peak)

- Software selectable holding current (per axis)
- Motor resolutions: 200 and 400, micro-stepping available
- Optional remote hand held terminal provides continuous status and position display
- 32 bit axis position registers provide ± 2,147,483,648 billion counts
- Velocity settings: up to 5 million pulses per second
- Position display in steps, inches, millimeters, centimeters, degrees, radians, or revolutions
- Relative, absolute, continuous, and jogging motions
- Closed loop operation (with optional incremental encoders)
- Encoder and or limit switch homing functions
- 4 hardware homing routines (with optional hardware position input)
- Programmable backlash correction (with encoder)
- Hardware and software emergency stop
- 3 hardware end limits per axis
- USB port interface for host computer control (with RS-422/485 drivers loaded on host computer)
- 3.27" tall x 19" wide x 16" deep rack mount chassis
- 120/240 VAC (switch selectable) 50/60 Hz, Amperage depends on size and number of axis

1.3 SYSTEM COMPONENTS

v.2

The components of the SMC motor controller are listed below. If you find any part missing from the shipment, please contact Thermionics Northwest.

Qty	Description
7	TMC Rack Mount Driver Unit
7	Hand held terminal with 10' cable (optional)
ſ	AC power cable
l per axis	15' Interface cable (with DB15 connectors)
l per axis	15' stepping motor cable
ſ	15' USB cable
ſ	TMC user manual
]	Communications driver installation CD

Section 2: System Overview

2.0 TMC CONTROLLER

The Thermionics TMC system consists of a motor control box which uses an MForce motor controller/driver, made by *Intelligent Motion Systems (IMS)*, for each axis. Each axis is capable of motor control and various I/O functions. TMC operational control is provided through the optional Hand Held Terminal, MCode commands sent from a user's computer or with custom developed software stored in each axis controller.

2.011 TMC HANDHELD TERMINAL

The Handheld Users Terminal is usually supplied in TMC controllers that have 3 or more axes. Through the terminal the user can control motor functions, many system settings, and monitor positional data. The Hand Terminal is described in section 7 or this manual.

2.012 MCODE COMMANDS

MCode is the native language used to setup, control and program IMS controllers. MCode is explained in the *Programming and Software Reference* manual which is provided with the TMC unit. It is also available for download at: http://www.imshome.com/downloads/manuals.html

2.3 TERMINAL SOFTWARE

v.2

The basic way to communicate with each axis is through terminal software. IMS provides free terminal software that is optimized to work with the MForce controllers which control each axis of the TMC. IMS Terminal is available for downloaded at:

http://www.imshome.com/downloads/software_interfaces.html

2.4 CUSTOM DEVELOPED SOFTWARE

Software can be written in MCode and downloaded and stored in each MForce controller. When called this stored software can perform motor control functions. There are programming instructions and examples in the *Programming and Software Reference* manual.

2.02 TMC Functional Diagram



3.1 PERSONNEL SAFETY

Only individuals who understand the contents of this manual, the IMS <u>MDrive</u> <u>Software Reference Manual</u> and all other relevant documentation are authorized to work on or with the TMC motor controller and related equipment. Working on or with this equipment includes operating, programming and adjusting the settings. These individuals must be able to detect and prevent improper actions and settings that may be dangerous to personnel and or equipment. They must be aware of the consequences of setting and changing parameter values and how these values effect the operation of mechanical, electrical and electronic equipment. They must have enough training, knowledge and experience to detect and avoid potential dangers. They must also be familiar with and follow the safety standards, procedures, and regulations that apply to the location where the TMC and related equipment is installed and operated.

3.2 INTENDED USE

v.2

The drive systems described here are products for general use that conform to the state of the art in technology and are designed to prevent any dangers. However, drives and drive controllers that are not specifically designed for safety functions are not approved for applications where the functioning of the drive could endanger persons.

The possibility of unexpected or unbraked movements can never be totally excluded without additional safety equipment. For this reason personnel must never be in the danger zone of the drives unless additional suitable safety equipment prevents any personal danger. This applies to operation of the machine during production and also to all service and maintenance work on drives and the machine. The machine design must ensure personal safety. Suitable measures for prevention of property damage are also required. In all cases the applicable safety regulations and the specified operating conditions, such as environmental conditions and specified technical data, must be observed.

The drive system must not be commissioned and operated until completion of installation in accordance with the specifications in this manual. To prevent personal injury and damage to property damaged drive systems must not be installed or operated.

Changes and modifications of the drive systems are not permitted and if made no warranty and liability will be accepted. The drive system must be operated only with the specified wiring and approved accessories. In general, use only original accessories and spare parts.

The drive systems must not be operated in an environment subject to explosion hazard (ex area). not avoided, can result in death, serious injury, or equipment damage.

Failure to follow these instructions can result in death or serious injury.

4.0 MOUNTING THE TMC CHASSIS

The TMC series controllers are manufactured to fit into a standard 19" electronics rack chassis or they can be used as a table top unit. We recommend shelf supports be utilized to handle the chassis weight in an electronics rack.

All of the necessary hardware is provided to make the connections between the controller, the hand held terminal, motors, end limit switches and USB port.

4.1 HAND HELD TERMINAL

The optional hand held terminal attaches to the front panel of the controller chassis with a 10 foot cable. The connection is labeled Hand Held Terminal. Use a screwdriver to tighten the two mounting screws on the connector. The TMC hand held terminal allows the controller to be operated as a completely standalone unit. Operation of the hand held terminal is described in Section 7.

4.2 REAR PANEL CONNECTIONS AND SETTINGS

A - Voltage selector switch - select 230V or 115V to match supply input voltage

B - Fuse - 1/4" by 1 1/4" 15 amp slow blow

C - Ethernet connection – standard 8P8C (often called RJ45) connection. This port is used only to communicate with the Hand Terminal. It is not required. It is only used for custom systems.

D - USB (type B) – communicates directly to RS-485 party line with the axis controllers.

E - Axis 1 to 6 I/O connectors (DB15 female) – These connectors provide user access to: clockwise (+) limit switch, counter clockwise (-) limit switch, optical zero position input (ZPI), and incremental encoder connections. There is one I/O connector per axis.

F - Axis I to 6 stepping motor output connectors (DB5W5). There is one connector per axis.

G - Hardware E-Stop connector.

H - AC Power connection – cord provided

4.3 USB COMMUNICATIONS PORT

v.2

This connection is used to communicate via the user's computer. A CD is provided with communications drivers that must be loaded on the user's computer to communicate through this port. (Note: this connection is used exclusively with the hand terminal turned off or removed from the TMC controller.)

4.4 I/O CONNECTIONS

Each axis has a unique I/O connector. Each is a DB15F (socket) connector labeled by its axis number (i.e. 1 to 6) on the TMC rear panel. The position designation for each connector is:

- 1. encoder channel A+
- 2. encoder channel A-
- 3. encoder channel B+
- 4. encoder channel B-
- 5. encoder index +
- 6. encoder index –
- 7. clockwise (+) limit switch signal (I/O 1)
- 8. counter clockwise (-) limit switch signal (I/O 2)
- 9. encoder 5 VDC supply
- 10. ZPI 5 VDC supply
- 11. ZPI 3.2VDC (220 ohms to 5VDC)
- 12. ZPI output signal (I/O 3)
- 13. ZPI ground
- 14. encoder ground
- 15. CW and CCW limit ground



I/O connector DB15F (socket) position layout on back panel

4.5 HARDWARE END LIMITS

Hardware end limits will cause the motor to stop moving when a limit switch contacts open. Each axis supports a clockwise (+) limit switch and a counter clockwise (-) limit switch. These are provided to protect delicate equipment from being damaged. The limit switches are typically mounted at each end of travel. When the motor travel activates a limit switch the motor is stopped and will not move any further in the same direction. The limits are prewired in the typical Thermionics installation. The limits are wired as follows:

٦C	CW (+) limit switch contacts Common (C)	I/O connector connected to position
	Normally closed (NC)	connected to position 7
15	CCW (-) limit switch contacts Common (C)	I/O connector connected to position
	Normally closed (NC)	connected to position 8

4.6 HARDWARE HOME LIMIT INPUT

The home limit can be used as a reference position to reset an axis positional counter.

4.61 OPTICAL HOME LIMIT (ZPI)



Figure 2.3 -Optical Sensor (bottom view)

The optical home limit is designed to work with the Honeywell HOA2004 series Opto-schmitt sensor. The figure on the right illustrates how to connect the switch.

The ZPI is prewired in the typical Thermionics installation. The ZPI is wired as follows:

HOA2004 sensor	I/O connector
+5 VDC	position 10
3.2V	position 11
Output	position 12
Gnd	position 13
Gnd	position 13

4.62 MECHANICAL HOME LIMITS

Any type of mechanical switch can be used for sensing the home position. The normally open (NO) switch contact is connected to I/O position 10 and the common (C) switch contact is connected to I/O position 12.

4.7 INCREMENTAL ENCODER INPUT

The TMC controller is capable of using information provided by an incremental encoder to accurately control the axis position. The index of the

v.2 TMC MOTOR CONTROLLER 3-6 AXES

encoder can be used in conjunction with the hardware home position inputs or the end limit switch inputs to achieve very accurate positioning. The encoder is prewired in the typical Thermionics installation. The encoder is wired as follows:

Encoder with differential outputs (8 wires)

Encoder connections channel A+ channel Achannel B+ channel Bindex + index – 5 VDC supply ground

channel A

channel B

5 VDC supply

index

ground

I/O connector position 1 position 2 position 3 position 4 position 5 position 6 position 9 position 14

Encoder with single-ended outputs (5 wires) Encoder connections

I/O connector position 1 position 3 position 5 position 9 position 14

4.8 MOTOR CONNECTORS

Each axis has a five position DB5W5 hybrid connector that supplies the output connections required for the stepper motors.

The motors are prewired in the typical Thermionics installation. The motors are wired as follows:

Encoder with differential output	s (8 wires)
Motor connections	Motor output
connector	
Phase A-	position A1
Phase A+	position A2
Phase B-	position A3
Phase B+	position A4

Note: Chassis ground is connected to position A5. This is connected to the cable shield and should not be connected to the motor.



Motor output connector DB5W5 (socket) position layout on back panel

4.9 HARDWARE EMERGENCY STOP

Activating the hardware emergency stop, also referred to as the E-Stop, will cause all motors to immediately stop.

A normally closed switch or button can be attached to position 2 and 3 of the CPC connector located on the back panel of the driver unit.

Note: The black CPC connector shipped with the unit must be attached to deactivate the E-Stop.

4.10 AC POWER CONNECTOR AND VOLTAGE SELECTOR SWITCH

Determine and install if needed the proper AC power plug for your region to the provided power cable.

Plug the power cable provided into the power connector on the rear of the unit.

Adjust the voltage selector switch to 115V or 230V to match the supply voltage.

4.11 TMC SENSOR CONNECTIONS

Encoder connections 6 position Molex Connector

Pin	Signal
#	
Ţ	not
	connected
2	Channel B
73	5 VDC
4	Index
5	Channel A
6	Ground

4.111 LIMIT SWITCH CONNECTIONS 6 POSITION MOLEX CONNECTOR

Pin	Signal	Limit Switch
#		wire
ſ	CW (+) switch – normally	Green
	closed (NC)	
2	CCW (-) switch – normally	Green

	closed (NC)	
3	not connected	-
4	CW (+) switch – common	Yellow
	(C)	
5	CCW (-) switch – common	Yellow
	(C)	
6	not connected	-

4.112 ZERO POSITION INDICATOR (ZPI) CONNECTIONS 6 POSITION MOLEX CONNECTOR

Pin	Signal	Limit Switch
#		wire
ſ	Ground	Green
2	Detector Output (signal)	Blue
3	VCC (5 VDC)	White
4	Anode (3.3V DC)	Red
5	not connected	_
6	Ground	Black

4.113 ENCODER, LIMIT SWITCH AND ZPI CONNECTORS PIN ASSIGNMENTS



Connector: Molex - P.N. 03-06-2061 Plug 6 position (pins) 0.062"spacing View from wire/cable side of connector

Section 5: System Setup

5.0 CABLING

There is a motor cable for each axis. An I/O cable is also supplied for each axis that is configured with hardware limit switches, ZPI or an encoder. A USB cable is also supplied.

IMPORTANT NOTE: Before turning on the power to the controller always

make sure that the components are securely and properly connected.

5.1 COMMUNICATIONS SETUP

5.11 CONFIGURING THE COMMUNICATION PORT

Communications between the customer supplied computer and the TMC is through the USB connection. Inside the TMC, the USB signals are converted to the RS422 communications bus by a model U485G converter made by U.S. Converters.

The user supplied computer will require the proper driver for the U485G converter. The driver can be downloaded from the supplied CD or by going to the US Converter's website:

Installation of the communications drivers from the CD

1) Insert the CD and view the folders

2) Open the ftdi_drivers_manuals folder

3) Open the 3_Driver installation guides folder

4) Open the pdf file that corresponds to the user computer operating system For example if the user computer has the Windows XP operating system open the file named <u>3_Windows Installation Guide XP_AN104FTDI.pdf</u>

5) Follow the directions in the pdf file to load the drivers.

6) Take note of the COM number for the USB Serial Port in the COM Port section of Device Manager. This number will need to match the port number setting in the IMS Terminal program Installation of the communications drivers from the web site

1) Download the software from the US Converters web site at:

http://www.usconverters.com/index.php?main_page=page&id=15&chapter=0 2) At the website:

Go to the section		USB to RS485 and RS422
Find the row for		U485G
Select		Drivers/Data Sheet.zip
3) Select	Save	

4) Save to a location on your Hard Drive

5) Unzip the downloaded folder by copying the contents of the zip folder into a new folder

6) Open the pdf file that corresponds to the user computer operating system For example if the user computer has the Windows XP operating system open the file named <u>3_Windows Installation Guide XP_AN104FTDI.pdf</u>

7) Follow the directions in the pdf file to load the drivers.

8) Take note of the COM number for the USB Serial Port in the COM Port section of Device Manager. This number will need to match the port number setting in the IMS Terminal program

5.12 Installing and Configuring Terminal Software

Terminal software makes it possible to communicate with the TMC motor controller. Each axis, in the TMC, is controlled and driven by an MForce controller/driver made by Intelligent Motion Systems Inc (IMS). We recommend using IMS Terminal which is a free terminal software package provided by IMS. IMS Terminal requires Microsoft Windows XP service pack 2 or higher.

Installation of the IMS Terminal software from the CD

1) Insert the CD and view the folders

- 2) Open the IMS_Term folder
- 3) Double click "setup.exe"

4) Follow the on-screen prompts to complete the installation of IMS Terminal

Installation of IMS Terminal software from web site

1) Download the software from the IMS web site at

http://www.imshome.com/downloads/software_interfaces.html.

2) Extract to a location on your hard drive.

3) In the folder location of the extracted files, double click "setup.exe"

4) Follow the on-screen prompts to complete the installation of IMS Terminal

A copy of the <u>MDrive Software Reference Manual</u> is located on the TMC CD and is labeled MCode[1].pdf

Section 6 of the <u>MDrive Software Reference Manual</u> describes the operation of IMS Terminal program.

Configuring the IMS Terminal software for the first time

Refer to Section 6.1.5 and 6.1.6 of the MDrive software Reference Manual on how to configure the terminal software.

The only thing that will need to be set, to begin communicating with the TMC, is the Comm port in the IMS Terminal program "Terminal" screen so it matches the USB Serial Port number in the COM Port section of Device Manager on the user computer. To do this:

1) Verify or change the Comm port setting in the IMS Terminal

The path to the COM port setting in IMS Terminal is:

Select Edit

Click on Preferences

Click on the Comm Settings Tab

The COM number setting is in the Port window

Once you have selected the correct com port, click ok.

2) Verify hardware and cable connections and apply power to the TMC.

3) If IMS Terminal program "Terminal Screen" is not already "connected", connect to the device by clicking the "connect" icon on the button bar, or by double

clicking the disconnected field on the status bar of the terminal window. 4) Key in ctrl+c.

5) The sign-on message below should appear.

Copyright 2001 - 2010 by Schneider Electric Motion USA

The sign-on message indicates that you are up and running. You may now begin to issue immediate mode commands and/or download programs to your device!

6.0 CONTROLLER OPERATION

All TMC stepping motor controllers are configured and tested at Thermionics so they are ready to operate without having to set any parameters. The TMC settings document, shipped with the controller, lists the settings resident in each axis of the TMC as it was shipped from Thermionics.

There are distinct differences in the way that single axis (that is not configured for the optional Hand Terminal) and multiple axis units communicate. These are described in the next sections.

6.01 COMMUNICATING WITH SINGLE AXIS SYSTEMS (NOT CONFIGURED FOR HAND TERMINAL)

- Start the IMS Terminal software.
- If IMS Terminal program "Terminal Screen" is not already "connected", connect to the device by clicking the "connect" icon on the button bar, or by double clicking the disconnected field on the status bar of the terminal window.
- Turn on the power switch on the TMC front panel.
- The Sign on message should display on the "Terminal" screen.

Copyright 2001 - 2010 by Schneider Electric Motion USA

Type in a command and then press the Enter key. As each character is typed the TMC will echo it back. commands for single axis systems are executed by the controller with the <ENTER> key or C/R character.

6.02 COMMUNICATING WITH MULTIPLE AXES SYSTEMS (AND SINGLE AXIS CONFIGURED FOR HAND TERMINAL)

When Party Mode is enabled, each device in the system must be addressed by the host computer by using the device name (specified by the MCode DN instruction). This name will precede any command given to a specified axis and be terminated with a Control J (CTRL + j buttons pressed simultaneously) or a L/F. One CTRL + J must be issued after power up or entering the Party Mode to activate the Party Mode.

Each multi axes TMC is initially set for the following commands that effect the Party Mode communications :

• Party Mode is set on (PY=1). This allows the axes to be address one axis at a time.

- The Echo Mode state is set to 2 (EM=2). The axes will only return information to the terminal window when given the MCode Print (PR) or List (L) commands.
- The Device Name (DN) for each axis is their labeled number. For example the axis labeled 1 has the device name (DN= "1") and the axis labeled 2 has the device name (DN="2") etc.

In the <u>MDrive Software Reference Manual</u> see section 4 for a summary and section 5 for complete instructions on MCode commands and settings.

Because the Party Mode is enabled, select CTRL + J to activate it at power up. To send a command, to a TMC axis, type the axis device name then the MCode command followed by CTRL + J.

To address all of the axes at once use the global device name which is the asterisk character (*).

Below are some examples of how party mode is implemented:

To move the axis labeled "1", press CTRL + J and then type: 1MR 10000 and press CTRL+J. device "1" will move 10000 steps.

To print the position of axis "1" type: 1PR P and press CTRL+J. The position of device "1" will be printed.

To move axis"2" type: 2MR 10000 and press CTRL+J. Device "2" will move 10000 steps.

To move all axes at the same time type: *MR 10000 and press CTRL+J. All axes will move 10000 steps.

To take a axis out of party mode and take put it into echo mode 0 type: <device name>EM=0 and press CTRL+J. The axis will be in echo mode 0 <device name>PY=0 and press CTRL+J. That axis will be taken out of party mode. Now this axis will communicate the same as a single axis controller. To avoid communications conflicts between the axes and the Terminal program it is important that to have no more than one axis out of party mode at a time.

To return an axis to party mode and put it back in echo mode 2 type: PY=1 and press ENTER. That axis will be returned to party mode. Press CTRL=J <device name>EM=2 and press CTRL+J. The axis will be back in echo mode 2.

6.1 HARDWARE END LIMITS SETTINGS

Axes that use hardware end limits are configured to use digital inputs 1 & 2.

v.2 TMC MOTOR CONTROLLER 3-6 AXES

When supplied, on the equipment provided by Thermionics, the axes with the limit switches are typically configured as follows:

S1=2,1,0 – Input 1 set for clockwise end limit, active high S2=3,1,0 – Input 2 set for counter-clockwise end limit, active high

With this configuration once a limit switch is met the motor will decelerate and stop. When the clockwise limit is met the motor will not move in the clockwise direction but will move in the counter clockwise direction. The opposite is true when the counter clockwise limit switch is met. When both limit switches are met the motor will not move in either direction.

Limit switch wiring is explained in section 4.5 of this manual.

IMPORTANT NOTE: When an axis is configured as above the motor will not move unless the limit switches are connected.

6.2 ZERO POSITION INDICATOR (ZPI) SETTINGS

The home limit input is used as a reference position where the axis positional counter can be reset.

Axes that use ZPI are configured to use digital inputs 1 & 2.

When supplied, on the equipment provided by Thermionics, the axes with the ZPI are typically configured as follows:

S3 = 1,0,1

ZPI wiring is explained in section 4.51 of this manual. The command for homing with a ZPI is the HM command. See section 5 of the <u>MDrive Software Reference</u> <u>Manual</u> for a description of *S3* and *HM* commands.

6.3 MCODE PROGRAMMING

Section 3 of the <u>MDrive Software Reference Manual</u> gives a detailed theoretical description how MCode software works. The instructions in it are a necessary overview.

6.4 MCODE COMMANDS

Section 4 of the <u>MDrive Software Reference Manual</u> gives a summary of the MCode commands.

Section 5 gives a full description for each of the MCode commands, settings and flags.

Please Note: The TMC uses the commands that have *MForce* and *MForce* (*Plus2* expanded features) listed under the "Compatible with Motion Control products:" listing.

6.5 INSTALLED PROGRAMS

Some special use TMC controllers are shipped from Thermionics with a resident program installed in one or both axes. Examples of these special uses are variable speed controller or target position controller. The TMC settings document, shipped with the controller, lists any programs resident in each axis of the TMC as it was shipped from Thermionics.

Section 7: Hand Terminal Operation

7.0 HAND TERMINAL

The optional hand terminal can control 1 to 6 axes. The function trees and flow charts below explain the functions of the hand terminal.

7.1 TMC HAND TERMINAL FUNCTION TREE (COMPRESSED VIEW)

FI Mo	ve Axis	
moves)	
1.1. F1	Single	Axis
ma	oves)	
1.1.1.	Select	: Single Axis
	1.1.1.1.	F1 Enter
	1.1.1.2.	F2 Refresh
	1.1.1.3.	F4 Return
	1.1.1.4.	F5 Stop All
1.1.2.	F1 Jo	g
	1.1.2.1.	F1 Move +
	1.1.2.2.	F2 Move -
	1.1.2.3.	F3 Stop move
	1.1.2.4.	F4 Return
	1.1.2.5.	F5 Stop All
1.1.3.	F2 M	ove Relative
	1.1.3.1.	F1 Set distance
		1.1.3.1.1. F1 Enter
		value)
		1.1.3.1.2. F4 Return
		1.1.3.1.3. F5 Stop All
	1.1.3.2.	F2 Move +
		distance)
	1.1.3.3.	F3 Move -
		distance)
	1.1.3.4.	F4 Return
	1.1.3.5.	F5 Stop All
1.1.4.	F3 M	ove Absolute
	1.1.4.1.	F1 Set Targets
		1.1.4.1.1. F1 Save
		screen)
		1.1.4.1.2. F2 Cancel
		screen)
		1.1.4.1.3. F3 Clear
		to zero)
	1.1.4.2.	F2 Move to next position
	1.1.4.3.	F3 Move to prior position
	1.1.4.4.	F4 Return
	1.1.4.5.	F5 Stop All
1.1.5.	F4 Re	eturn
1.1.6.	F5 St	op All
1.2. F2	Multip	ble Axes
ma	oves)	
1.2.1.	F1 Tv	vo axis Joq

(set up and executes axis or axes

(set up and executes single axis

(select axis for single axis move) (confirm selected axis) (clear selected axis) (return to next higher menu) (stops all motors) (momentary or continuous move) (moves selected axis in + direction.) (moves selected axis in - direction) (stops all motors) (return to next higher menu) (stops all motors) (moves axis a set distance) (user selects target distance) (enters and saves selected

(return to next higher menu) (stops all motors) (moves in + direction to target

(moves in – direction to target

(return to higher menu) (stops all motors) (moves axis a to a selected position) (user input of 6 positions) (saves positions & return to prior

(cancel selected & return to prior

(clears all positions & sets them

(moves from present to next position) (moves to prior position) (return to higher menu) (stops all motors) (return to higher menu) (stops all motors) (sets up and executes multiple axes

(X and Y axis Moves)

TMC MOTOR CONTROLLER 3-6 AXES

1.2.1.1. F1 Select X/Y Axes 1.2.1.1.1. F4 Return 1.2.1.1.2. F5 Stop All 1.2.1.2. F2 X/Y Speed Speed) 1.2.1.2.1. F1 Selects X/Y Axes 1.2.1.2.2. F2 X/Y Speed 1.2.1.2.3. F4 Return 1.2.1.2.4. F5 Stop All 1.2.1.3. F4 Return 1.2.1.4. F5 Stop All 1.2.2. F2 Move Relative 1.2.2.1. F1 Set Distances 1.2.2.1.1. F1 Set Distance screen) 1.2.2.1.1.1. F1 Enter 1.2.2.1.1.2. F4 Return 1.2.2.1.1.3. F5 Stop All 1.2.2.1.2. F2 Down 1.2.2.1.3. F3 Up 1.2.2.1.4. F4 Return 1.2.2.1.5. F5 Stop All 1.2.2.2. F2 Move + 1.2.2.3. F3 Move -1.2.2.4. F4 Return 1.2.2.5. F5 Stop All 1.2.3. F3 Move Absolute positions) 1.2.3.1. F1 Set Positions 1.2.3.1.1. F1 Set Positions 1.2.3.1.1.1. F1 Enter 1.2.3.1.1.2. F4 Return 1.2.3.1.1.3. F5 Stop All 1.2.3.1.2. F2 Down 1.2.3.1.3. F3 Up 1.2.3.1.4. F4 Return 1.2.3.1.5. F5 Stop All 1.2.3.2. F2 Move Axes 1233 E4 Return 1.2.3.4. F5 Stop All 1.3. F3 Home Axes 1.3.1. F1 Select axis 1.3.1.1. Fl Enter 1.3.1.2. F2 Refresh 1.3.1.3. F4 Return 1.3.1.4. F5 Stop All 1.3.2. F2 Home selected axes) 1.3.3. F3 Home all 134 F4 Return 1.3.5. F5 Stop All 1.4. F4 Return

(selects set up screen for X Y moves) (return to higher menu) (stops all motors) (selects set up screen for low or High (selects set up screen for X Y moves) (saves speed & return to higher menu) (returns to higher menu) (stops all motors) (return to higher menu) (stops all motors) (moves multiple axes set distances) (selects target distance set up screen) (selects distance numeric entry (saves value & returns to higher menu) (returns to higher menu) (stops all motors) (selects next axis) (selects prior axis) (returns to higher menu) (stops all motors) (moves target distances in + direction) (moves target distances in - direction) (return to higher menu) (stops all motors) (moves multiple axes to selected (user input of target positions) (selects position numeric entry screen) (saves value & returns to higher menu) (returns to higher menu) (stops all motors) (selects next axis) (selects prior axis) (returns to higher menu) (stops all motors) (moves axes to selected positions) (return to higher menu) (stops all motors) (homes axis/axes) (user selects which axis to home) (saves axis & returns to higher menu) (clears chosen axis) (return to higher menu) (stops all motors) (executes homing function to selected (executes homing function to all axes) (return to higher menu)

(stops all motors)

(return to higher menu)

1.5. F5 Stop All 2. F2 System Setup 2.1. Enter Password 2.1.1. F1 Enter next menu) 2.1.2. F4 Return 2.1.3. F5 Stop All 2.2. F1 System 2.2.1. Fl Password 2.2.1.1. Fl Save 2.2.1.2. F2 Access Level 2.2.1.3. F4 Return 2.2.1.4. F5 Stop All 2.2.2. F2 Language 2.2.2.1. Fl Save 2.2.2.2. F4 Return 2.2.2.3. F5 Stop All 2.2.3. F3 Technical Support information) 2.2.3.1. F4 Return 2.2.3.2. F5 Stop All 2.2.4. F4 Return 2.2.5. F5 Stop All 2.3. F2 Axis Parameter parameters) 2.3.1. F1 Next 2.3.2. F2 Prior 2.3.2.1. Display Settings units) 2.3.2.1.1. Select Axis 2.3.2.1.2. Increment rev.) 2.3.2.1.3. Steps Per Increment coordinate) 2.3.2.1.4. Display Precision 2.3.2.1.5. Speed Display Units 2.3.2.1.6. Default 2.3.2.2. Motor Settings 2.3.2.2.1. Select Axis 2.3.2.2.2. Motor Holding Current 2.3.2.2.3. Hold Current Delay Time 2.3.2.2.4. Motor Run Current 2.3.2.2.5. Acceleration Rate 2.3.2.2.6. Deceleration Rate 2.3.2.2.7. Initial Velocity 2.3.2.2.8. Maximum Velocity 2.3.2.2.9. Micro-Step Resolution 2.3.2.2.10. Motor Direction for + 2.3.2.3. Speed Settings (Steps/Second) 2.3.2.3.1. Select Axis 2.3.2.3.2. Jog Low Speed 2.3.2.3.3. Jog High Speed

(stops all motors) (system functions and parameters) (enter password screen) (password entered & proceed to (return to higher menu) (stops all motors) (access to system settings) (opens change password screen) (saves new password) (selects level 1 or 2 password) (return to higher menu) (stops all motors) (opens language selection screen) (saves selected language) (return to higher menu) (stops all motors) (technical support contact (return to higher menu) (stops all motors) (return to higher menu) (stops all motors) (view and modify system (displays next set of settings) (displays prior set of settings) (coordinates, precision, speed (select axis to view or change) (steps, inches, mm, cm, deg., rad., or (motor or encoder steps per (0, 0.0, 0.00, or 0.000) (second, minute or hour) (reset to defaults) (motor parameters) (select axis to view or change) (MDrive command HC) (MDrive command T) (*MDrive command* RC) (MDrive command A) (MDrive command D) (MDrive command VI) (MDrive command VM) (MDrive command MS) (clockwise or counter clockwise) (speed parameters) (select axis to view or change) (steps per second) steps per second)

TMC MOTOR CONTROLLER 3-6 AXES

2.3.2.4. Encoder Settings 2.3.2.4.1. Select Axis 2.3.2.4.2. Encoder Enable 2.3.2.4.3. Encoder Line Count 2.3.2.4.4. Encoder Dead-Band 2.3.2.4.5. Position Maintenance 2.3.2.4.6. Stall Factor 2.3.2.4.7. Stop on Stall 2.3.2.5. Homing Settings 2.3.2.5.1. Select Axis 2.3.2.5.2. Home Device 2.3.2.5.3. Home Sequence Type to 4) 2.3.2.5.4. Zero Position Offset 2.3.2.6. Stop Limit Settings 2.3.2.6.1. Select Axis 2.3.2.6.2. Stop Limit Mode 2.3.3. F3 Save or Reset 2.3.3.1. F1 Single Axis 2.3.3.1.1. Fl Save commands) 2.3.3.1.2. F2 Reset 2.3.3.1.3. F4 Return 2.3.3.1.4. F5 Stop All 2.3.3.2. F3 Save All Axes 2.3.3.2.1. Fl Save 2.3.3.2.2. F2 No saving) 2.3.3.2.3. F5 Stop All 2.3.3.3. F2 Reset All Axes 2.3.3.3.1. Fl Save 2.3.3.3.2. F2 No resetting) 2.3.3.3.3. F5 Stop All 2.3.3.4. F4 Return 2.3.3.5. F5 Stop All 2.3.4. F4 Return 2.3.5. F5 Stop All 2.4. F4 Return 2.5. F5 Stop All 3. F3 Custom Control 3.1. Enter Password 3.1.1. F1 Enter next menu) 3.1.2. F4 Return 3.2. F5 Stop All 3.3. F1 Direct Command controllers) 3.4. F2 E-gear settings moves) 3.4.1. F1 Set Up 3.4.1.1. F4 Return

(encoder parameters) (select axis to view or change) (MDrive command EE) (MDrive command EL) (MDrive command DB) (MDrive command PM) (MDrive command SF) (MDrive command SM) (homing parameters) (select axis to view or change) (limit switch/ZPI – HM or Encoder - HI) (MDrive selection for HM or HI] (position offset in steps from home) (stop limit parameters) (select axis to view or change) (MDrive selection for LM) (save or reset axis parameters) (selects save screen) (save individual axis MDrive (resets non MDrive commands) (returns to higher menu) (stops all motors) (selects save all screen) (saves all axis MDrive commands) (returns to higher menu without (stops all motors) (save or reset multiple axes) (reset non MDrive commands) (returns to higher menu without (stops all motors) (return to higher menu) (stops all motors) (return to higher menu) (stops all motors) (return to higher menu) (stops all motors) (special motor control options) (enter password screen) (password entered & proceed to (return to higher menu) (stops all motors) (direct Mcode commands to

(sets up multiple axis "gear ratio"

(selects E-gearing set up screen) (return to higher menu)

TMC MOTOR CONTROLLER 3-6 AXES

3.4.1.2. F5 Stop All 3.4.2. F2 ON/OFF 3.4.3. F4 Return 3.4.4. F5 Stop All 3.5. F4 Return 3.6. F5 Stop All 4. F4 Status 4.1. F1 Clear Errors

- 4.2. F2 Startup Position power-up values)
- 4.3. F3 Clear Startup
- 4.4. F4 Return
- 4.5. F5 Stop All
- 5. F5 Stop All

(stops all motors) (toggles E-gearing function on and off) (return to higher menu) (stops all motors) (return to higher menu) (stops all motors) (displays current axis information) (clears axes errors) (saves current positions to

(power-up positions will be 0) (return to higher menu) (stops all motors) (stops all motors)



7.2 TMC HAND Key to symbols w Value chosen by (description)	TERMINAL FUNCTION T used below F1 to F5 - Hand Termin user in existing window Value determined else *, ** - annotation Information Displayed	REE (expanded view) al function keys (values are examples) where (values are examples) on Screen
1. F1 Move Axis/Axes		(set up and executes axis/axes
moves and homing fun 1.1. F1 Single axis moves)	ctions)	(set up and executes single axis
1.2. 1.2.1. Select Single	e Axis	(axis selection screen pops up
when single	axis move is sele	cted)
(select the desir keys and confirm 1.2.1.1. F1	ed axis with the ↑ or ↓ ar n by pressing enter.) 	Axis 1 A Axis 2 Axis 3 A (confirm axis selected)
1.2.1.2. F2	Refresh	(clears selected axis)
1.2.1.3. F4	Return	(return to next higher menu)
1.2.1.4. F5 1.2.2. F1 Jog move)	Stop All	(stops all motors) (execute momentary or continuous
(displays current of the selected a * precision is bas ** measured uni	c position) Current Position (*position is based on t ixis. sed on 2.3.2.1.4. Display pr t is based on 2.3.2.1.2. Incr	he Axis Query - Current Coordinate recision. rement.)
(displays Low sp	eed jog rate) Low Sp	beed

TMC MOTOR CONTROLLER 3-6 AXES

28 |

*speed rate is based on 2.3.2.3.2. Jog Low Speed
*precision is based on 2.2.2.1.4. Display precision
** unit is based on 2.3.2.1.2. Increment
***time unit is based on 2.3.2.1.5 Speed Display Units)

(displays High speed jog rate)

High Speed 20000*

*speed rate is based on 2.3.2.3.3. Jog High Speed *precision is based on 2.2.2.1.4. Display precision ** unit is based on 2.3.2.1.2. Increment ***time unit is based on 2.3.2.1.5 Speed Display Units)

Momentary
Continuous

Low Speed Hiah Speed

Low Speed/High Speed* 1000** steps*** per sec.****

(*user toggles between Low Speed or High Speed.

**speed rate is based on 2.2.2.3. Jog Low Speed or Jog High Speed

** precision is based on 2.2.2.1.4. Display precision

***Type of coordinate is based on 2.2.2.1.2. Coordinates

****time unit is based on 2.2.2.1.5 Speed Units Display settings)

```
Jogging +*
```

(displays active move)

(This window is displayed only when the Axis Query - Moving Status for the selected

axis is VM=1

* + or – displayed depending on whether 1.1.1.1. F1 Move + or 1.1.1.2 F2 Move – executed

move)

1.1.1.1. FI Move	÷ +		(move	es selected axis in +
direction	1.)			
Example: If Low Speed	d/High Speed		is	toggled to Low
and 2.2.2.10. Motor [Direction for +		is	set for CW (+1)
and 2.2.3.2. Jog Low 9	Speed	is	2000	
and 2000 x +1= 2000				
then:				

TMC MOTOR CONTROLLER 3-6 AXES

	§nSL_2000§	(com	mand	sent on com bus)	
Note if 2.2.2.2.10. Motor In the prior example 2000 x -1= -2000	Direction for +		İS	set for CCW (-1)	
inen.	§nSL2000§		(comr	mand sent on com bus)	
1.1.1.2. F2 Move	-		(move	es selected axis in -	
Example: If Low Speed and 2.2.2.2.10. Motor D and 2.2.3.2. Jog Low S and -2000 x +1= -2000 then:	/High Speed Direction for + Speed	is	is is 2000	toggled to Low set for CW (+1)	
	§nSL2000§		(comr	mand sent on com bus)	
Note if 2.2.2.2.10. Motor In the prior example -2000 x -1= 2000 Then:	Direction for +		is	set for CCW (-1)	
	§nSL_2000§	(com	mand	sent on com bus)	
1.1.1.3. F3 Stop §nSL_0§ (com	move mand sent on con	(stops r h bus)	move)		
1.1.1.4. F4 Retui	în		(retur	n to next higher menu)	
1.1.1.5. F5 Stop ,	А	(stops d	all motor.	s)	
1.1.2. F2 Move Relative(moves axis a set distance)Target distance 5.50* inches**(displays target distance)(*Target distance is based on 1.1.2.1. F1 Set distance* precision is based on 2.2.2.1.4. Display precision**Type of coordinate is based on 2.2.2.1.2. Coordinates)					
Current Position 1.77* (*position is based on t axis. * precision is based on 2 **Type of coordinate is	inches** (display he Axis Query - Cu 2.2.2.1.4. Display pre based on 2.2.2.1.2. C	vs currer rrent (ecisior Coordin	nt positio Coordii N nates)	ⁿ⁾ nate of the selected	
Continuous Move On (This mode defaults to commanded	OFF (togg OFF. When toggle	les co ed ON	ntinuo the co	<i>us mode on or off</i>) ntrollers are continually	

v.2

to move back and forth between Move+ and Move- until the user selects OFF.

This mode does not start until F2 Move + or F3 Move – are selected. The axis completes each moves (Axis Query - Moving Status" for the axis is VM=0)

before the command is given for the next move.)

E-gearing ON*

(*this box is displayed when the E-gearing is activated 3.2,)

Moving +*

(displays active move)

(This window is displayed only when the Axis Query "Moving Status" for the selected

axis is VM=1

* + or – displayed depending on whether 1.12.2. F2 Move + or 1.1.2.3. F3 Move - executed

move)

1.1.2.1. F1 Set distance

Target Distance 5.50* inches**

(*user selects target distance here

* precision is based on 2.2.2.1.4. Display precision

**Type of coordinate is based on 2.2.2.1.2. Coordinates)

 11.2.2. F2 Move +
 (moves in + direction)

 Example: If 1.1.2.1. Target Distance
 is
 5.50

 and
 2.2.2.2.10. Motor Direction for +
 is
 set for CW (+1)

 and
 2.2.2.1.3. Steps Per Coordinate
 is
 512000

 and
 since 5.50 x +1 x 512000 = 2560000
 (move size)

 then:
 then:
 then:

§nMR_2560000§ (command sent on com bus)

1.1.2.3.F3Move -(moves in - direction)Example: If 1.1.2.1. Target Distanceis5.50and 2.2.2.2.10. Motor Direction for +isset for CW (+1)and 2.2.2.1.3. Steps Per Coordinateis512000and since- $5.50 \times +1 \times 512000 = -2560000$ (move size)then:50MD = 25600005(command sent on com hum)

§nMR_-2560000§ (command sent on com bus) 1.1.2.4. F4 Return (return to higher menu)

1.1.2.5. F5 Stop All

(stops all motors)

(user selects target distance)

Selected Position A* 1000** steps*** (displays current or selected target position)

(Position information is blank when 1.1.3 F3 Move Absolute is first opened. *position is the Target Position of the currently selected target based on current

chosen position when 1.1.3.2. F2 Move to Next Position or 1.1.3.3. F3 Move to Prior

Position are selected.

**precision is based on 2.2.2.1.4. Display precision

***Type of coordinate is based on 2.2.2.1.2. Coordinates)

Current Position 526* steps** (displays current position)

(*position is based on the Axis Query - Current Coordinate of the selected axis.

* precision is based on 2.2.2.1.4. Display precision

**Type of coordinate is based on 2.2.2.1.2. Coordinates)

Moving to position A st

(displayed only during move)

(*Displays the target number being moved to.)

1.1.3.1. F1 Select Target Positions (user input of 6 positions)

Position A 100* mm**	(
Position B <mark>20*</mark> mm**	
Position C <mark>502*</mark> mm ^{**}	(
Position D - <mark>100*</mark> mm**	(
Position E <mark>-250*</mark> mm**	(
Position F -5020* mm*	* (

(user selects A position target distance)
(user selects B position target distance)
(user selects C position target distance)
(user selects D position target distance)
(user selects E position target distance)
(user selects F position target distance)

(*user selects target distance here

* precision is based on 2.2.2.1.4. Display precision

**Type of coordinate is based on 2.2.2.1.2. Coordinates)

Clear all positions (returns all position values to 0)

1.1.3.2. F2 Move to Next Position (to next position)

(i.e. moves from A to F)

(The first move after the 1.1.3. F3 Move Absolute window is opened will be to A) Example: If the position prior to move is A the next position will be B.

and position B

is 20

and 2.2.2.1.3. Steps Per Coordinate is 20157 and since 20x20157=403140 (target position in steps) then:

§nMA_403140§ (command sent on com bus)

1.1.3.3. F3 Move to Prior Position *(moves to prior position)* (i.e. moves from A to F)

(The first move after the 1.1.3. F3 Move Absolute window is opened will be to F) (move commands the same as example in 1.1.3.2. F2 Move to Next Position but with the move proceeding to prior target position)

1.1.3.4. F4 Return (return to higher menu) 1.1.3.5. F5 Stop All (stops all motors) 1136 1.1.4. F4 Return (return to higher menu) 1.1.5. F5 Stop All (stops all motors) 1.2. F2 Multiple Axes (sets up and executes multiple axes moves) 1.2.1. F1 Two axis Jog (X and Y axis Moves with $\leftarrow \rightarrow \uparrow \downarrow$ keys) (This Type move uses the Hand Terminal arrow keys to execute moves. The move is commanded to start when an arrow key is depressed and commanded to stop when the key is released. It will work on one of the eight arrow keys at a time. The first arrow key depressed controls movement until it is depressed. The corner arrow keys command both axes to move at the same time.) Example of up/down or left right arrow commands: If Low Speed/High Speed is toggled to High and 1.2.1.1. Assign axis to X moves ← → İS axis 2 and 2.2.2.2.10. Motor Direction for + (axis 2) İS set for CW (+1) and 1.2.1.1. Assign axis to Y moves ↑↓ İS axis 4 and 2.2.2.2.10. Motor Direction for + (axis 4) is set for CW (-1) and 1.2.1.1. Set Axis → is CW and 1.2.1.1. Set Axis ↑ CW is and 2.2.3.3. Jog High Speed 500000 is and since 500000 x +1= 500000 will be used for axis 2 and since 500000 x -1= -500000 will be used for axis 4 then: $S2SL_500000$ (command sent on com bus when \rightarrow key is pressed) Followed by: §2SL_0§ (command sent on com bus as soon as key is released) or (command sent on com bus when key is pressed) §2SL_-500000§

Followed by:

v.2

:§2SL_0§ (command sent on com bus as soon as key is released)

TMC MOTOR CONTROLLER 3-6 AXES

or $4SL_{50000}$ (command sent on com bus when \uparrow key is pressed) Followed by: §4SL_0§ (command sent on com bus as soon as key is released) or (commands sent on com bus when up left key is pressed) §2SL_-50000§ and §4SL_-500000§ Followed by: §2SL_0§ (command sent on com bus as soon as key is released) and §4SL_0§ X position10.03* mm** (displays current X position) (*position is based on the Axis Query - Current Coordinate of the selected axis. * precision is based on 2.2.2.1.4. Display precision **Type of coordinate is based on 2.2.2.1.2. Coordinates) Y position -20.5* mm** (displays current Y position) (*position is based on the Axis Query - Current Coordinate of the selected axis. * precision is based on 2.2.2.1.4. Display precision **Type of coordinate is based on 2.2.2.1.2. Coordinates) Low Speed/High Speed* 1000** steps*** per sec.**** (*user toggles between Low Speed or High Speed. **speed rate is based on 2.2.2.3. Jog Low Speed or Jog High Speed ** precision is based on 2.2.2.1.4. Display precision ***Type of coordinate is based on 2.2.2.1.2. Coordinates ****time unit is based on 2.2.2.1.5 Speed Units Display settings) Jogging X* (displayed during move only) (This window is displayed only when one of the arrow keys is pressed *window will display: Jogging X button is pressed when ← ∩r → Jogging Y when ↑ or ↓ button is pressed or

1.2.1.1. F1 Select axes

1.2.1.1. FI SEIEC	Laxes	(sets up		JVES)
Assign axis to x moves	(← →) <mark>1 2 3</mark> (Assign axis t	determines x axis o y moves (↑↓) ·) 1 2 3	(determines y
Set → for CW or CCW Set ↑ for CW or CCW	(determines) (deterr	direction of x mines directio	axis moves) on of y axis mov	/es)
1.2.1.2. F4 Retu	rn	(re	eturn to higher	menu)
1.2.1.3. F5 Stop	All	(st	ops all motors)	
1.2.2. F2 Move Relative Current Position Axis 1 526.0* mm** Axis 2 20.7* mm** Axis 3 -47.9* deg.** Axis 4 -2.0* mm** Axis 5 526.9* mm** Axis 6 39888* steps** (*position is based on t * precision is based on	(displa he Axis Query 2.2.2.1.4. Displa	(moves ys current axi - Current Coc ay precision	multiple axes s s positions) ordinate of the s	et distances) selected axis.
**Type of coordinate is	based on 2.2.2	.1.2. Coordina ⁻	tes)	
Continuous Move On or off)	OFF (user selects t	oggles continu	ous mode on
(This mode defaults to	OFF. When to	oggled ON the	e controllers are	e continually
to move back and forth This mode does not sta All of the axes complet axes is MV=0)	n between Mo art until F2 Mo e their moves	ve+ and Move ve + or F3 Mo (Axis Query "I	e- until the user ve – are selecte Moving Status"	r selects OFF. ed. for the all
before the command is	s given for the	next move.)		
Moving + (or -) (This window is display any axes is MV=1.)	(displa) ed only when	yed during m the Axis Quei	iove only) ry "Moving Stat	us" for the

1.2.2.1. F1 Select Target Distances (user select target distances for axes)

(user can choose any combination of one to all available axes Notes: The axes shown correspond to the axis available in the TMC. The boxes of the axes chosen will light up.)

ine c	poxes of the axes of	chosen will light up).)	
Targe	et Distance			
Axis	1 150* mm**	(user selects targ	et dist	ance for axis 1)
Axis 2 mm** (user selects ta			et dist	ance for axis 2)
Axis 3	3 -80* deg.**	(user select	ts tarq	et distance for axis 3)
Axis 4	4 mm**	(user selects targ	et dist	ance for axis 4)
Axis ^c	5 mm**	(user selects targ	et dist	ance for axis 5)
Axis	$5 - 17500^* \text{ steps}^{**}$	(user selects targ	et dist	cance for axis 6)
(*1100	r salacts target dis	stance on selected	avic h	ara
* pred	rision is based on	22214 Display pr	ecisior	
**Tvn	e of coordinate is	hased on 22212 (°oordi	
ΥΥΡ		00300 011 2.2.2.1.2.	coordi	nacco)
	1222 E2 Move	<u>></u> +		(moves in + direction)
Exam	nple: If 1.2.2.1 Targe	et Distance Axis 1		is 150
and	2.2.2.2.10. Motor E	Direction for + (axis	٦)	is set for CW (+1)
and	2.2.2.1.3. Steps Pe	r Coordinate (axis ⁻	1)	is 20157
and	since 150 x +1 x 2	20157 = 3023550		(axis 1 move size)
and	1.2.2.1 Target Dist	ance Axis 3	is	-80
and	2.2.2.2.10. Motor E	Direction for + (axis	3)	is set for CW (+1)
and	2.2.2.1.3. Steps Pe	r Coordinate (axis I	3)	is 142
and	since -80 x +1 x 1	42 = -11360	(axis	3 move size)
and	1.2.2.1 Target Dist	ance Axis 6	is	-17500
and	2.2.2.2.10. Motor E	Direction for + (axis	6)	is set for CW (+1)
and	2.2.2.1.3. Steps Pe	r Coordinate (axis (6)	IS I
and	since -17500 x +	x = -17500		(axis 6 move size)
then:			(
		91MR_30235509	(com	mand sent on com bus)
		311U 87MD 117608	lcom	mand cont on com buc)
		95141R115009	(COTT	mand sent on corribus)
		86MD 175008	lcom	mand cont on com bus)
		30141K- 173003	(COIII	mand sent on corr bus,
	1223 F3 Move	2 _		(moves in - direction)
(mov	e same as 1222 F	/ 2 Move + with mov	/e size	x -1
Exam	nple:		0	
§1MR	3023550§ (com	nmand sent on cor	n bus)	
	- \	and	,	

TMC MOTOR CONTROLLER 3-6 AXES

(command sent on com bus)

and §6MR_17500§

§3MR_11360§

(command sent on com bus)

1.2.2.4. F4 Return (return to higher menu)

1.2.2.5. F5 Stop All

(stops all motors)

1.2.3. F3 Move Absolute positions)

Current Position

Axis 1 526.0* mm** Axis 2 20.7* mm** Axis 3 -47.9* deg.** Axis 4 -2.0* mm** Axis 5 526.9* mm** (moves multiple axes to selected

(displays current axis positions)

Axis 6 39888* steps** (*position is based on the Axis Query - Current Coordinate of the selected axis. * precision is based on 2.2.2.1.4. Display precision

**Type of coordinate is based on 2.2.2.1.2. Coordinates)

Moving Axes

(displayed only during move)

(This window is displayed only when the Axis Query "Moving Status" for the any

axes is MV=1.)

1.2.3.1. F1 Select Target Positions (user input of target positions)) (user can choose any combination of one to all available axes Notes: The axes shown correspond to the axis available in the TMC. The boxes of the axes chosen will light up.)

Target Position	
Axis 1 100* mm	**
Axis 2 mm**	
Axis 3 - <mark>25*</mark> deg.	**
Axis 4 mm**	
Axis 5 mm**	
Axis 6 - <mark>5020*</mark> st	eps*

(user selects target position for axis 1)

(user selects target position for axis 2)

(user selects target position for axis 3)

(user selects target position for axis 4)

(user selects target position for axis 5)

(user selects target position for axis6)

(*user selects target position on selected axis

* precision is based on 2.2.2.1.4. Display precision

**Type of coordinate is based on 2.2.2.1.2. Coordinates)

 Clear all positions
 (returns all position values to blank)

 TMC MOTOR CONTROLLER 3-6 AXES

1.2.3.2. F2 Move Axes (moves all of the selected axes) Example: If 1.2.3.1. Position Axis 1 is selected to be 100 and 2.2.2.1.3. Steps Per Coordinate (axis 1) is 20157 and since 100 x 20157 = 20175700 (target position in steps) and 1.2.3.1. Position Axis 3 is selected to be 25 and 2.2.2.1.3. Steps Per Coordinate (axis 3) is 142 and since 25 x 142 = 3550 (target position in steps) and 1.2.3.1. Position Axis 6 is selected to be -5020 and 2.2.2.1.3. Steps Per Coordinate (axis 6) is 1 then: since -5020 x 1 = -5020 (target position in steps) §1MA_20175700§ (command sent on com bus) and §3MA_3550§ (command sent on com bus) and §6MA_-5020§ (command sent on com bus) 1.2.3.3. F4 Return (return to higher menu)

1.2.3.4. F5 Stop All

(stops all motors)

1.3. F3 Home Axes

Homing

(homes axis/axes)

(displayed during move only)

(This window is displayed only when 1.3.2. F2 or 1.3.3. F3 have been selected and

Axis Query "Moving Status" for any axes is MV=1.)

Homing completed (displayed when moves are completed) (This window is displayed only after "Homing" window has been displayed and Axis

**

Query "Moving Status" for the all axes is MV=0.)

1.3.1. F1 Select axis Axis 1 2 3 4 ...

(user selects which axis to home)

Reset* selected axis position to _

(allows user to reset axis position)

38 |

(*user chooses to reset axis position value)

(**user chooses the new position value- defaults to 0)

Are you sure you want to reset the position value/counter on axis $_n^*$ to <u>nnn</u>**? Yes

(This window is displayed only when the RESET Button has been selected) TMC MOTOR CONTROLLER 3-6 AXES

(*The selected axis is displayed) (**The position value that the user chose is displayed) (Selecting YES will run the following command) example: If user selected axis 5 and a position value of 500 the following command is sent: §5P=500§ (command sent on com bus) 1.3.2. F2 Home selected axis (home selected axes) (command as follows for each selected axis) Home command for all axis where 2.2.2.4.2. Encoder Enable (EE) =0 example: If 2.2.2.5.3. Home Sequence Type (1,2,3 or 4) is 1 (command sent on com bus) §nHM_1§ Monitor the axis to determine when the move is completed §nPR_MV§ (axis will return 1 while moving and 0 when complete) Once the move is complete, MV=0, reset the counter to zero position offset based on The value this axis has at 2.2.2.5.4. Zero Position Offset (example if the axis homed has a Zero Position Offset value of 2500, command as follows) §nC1=2500§ Home command for all axis where 2.2.2.4.2. Encoder Enable (EE) =1 example: If 2.2.2.5.3. Home Sequence Type (1,2,3 or 4) is 3 §nHI_3§ (command sent on com bus) Monitor the axis to determine when the move is completed §nPR_MV§ (axis will return 1 while moving and 0 when complete) Once the move is complete, MV=0, reset the counter to zero position offset based on The value this axis has at 2.2.2.5.4. Zero Position Offset (example if the axis homed has a Zero Position Offset value of 500, command as follows) §nC2=500§

1.3.3. F3 Home all (command as follows for all available axis)

(home all axes)

39 |

Home command for all axis where 2.2.2.4.2. Encoder Enable (EE) =0 TMC MOTOR CONTROLLER 3-6 AXES

	example: If 2.2.2.5.3. Home Sequer §nHM_1§ (com	nce Type (1,2,3 or 4) is 1 Inmand sent on com bus)						
	Monitor each axis one at a time to determine when the moves are completed §nPR_MV§ (axes will return 1 while moving and 0 when complete)							
	Once each move is complete, MV= position offset based on The value each axis is at 2.2.2.5.4.2 (example if the axis homed has a Z as follows) §nC1=200§	0, reset the counters for each axis to zero Zero Position Offset Zero Position Offset value of 200, command						
	Home command for all axis where example: If 2.2.2.5.3. Home Sequen §nHI_2§ (com	2.2.2.4.2. Encoder Enable (EE) =1 nce Type (1,2,3 or 4) is 2 nmand sent on com bus)						
	Once each move is complete, MV= position offset based on The value each axis is at 2.2.2.5.4.2 (example if the axis homed has a Z command as follows) §nC1=2200§	0, reset the counters for each axis to zero Zero Position Offset Zero Position Offset value of 2200,						
	1.3.4. F4 Return	(return to higher menu)						
	1.3.5. F5 Stop All	(stops all motors)						
1.4	F4 Return	(return to higher menu)						
1.5.	F5 Stop All	(stops all motors)						
2. F2	2 System Setup	(system functions and parameters)						
2.1.	F1 System Parameters parameters)	(access to system functions and						
	Version number	(displays QSI configuration version)						
	2.1.1. F1 Password levels)	(input of user passwords – 2						

v.2

TMC MOTOR CONTROLLER 3-6 AXES

40 |

Enter password ___

(level one password needed to change parameters in 2.2 or 2.3 Level two password needed to use 3. Direct Motor Commands)

2.1.2. F2 Language

Engl	lish	

(choose language) (user selects Hand Terminal language) (for future languages)

	2.1.3. F3 inf Contac Therm 231-B C Port Tc Teleph Fax: 36 email: <u>s</u>	Tech formationics otto S ownse one: 8 0-385 suppc	nnical Supp tion) S Northwes treet and, WA 98 300-962-23 5-6617 ort@therm	bort t, Inc. 368 10 or 360-3 ionics.com	85-7707	(tech	inical s	suppo	rt	
	2.1.4. F4	. Reti	urn			(return to h	nigher	menu	1)	
	2.1.5. F5	Stop	o All			(stops all moto	ors)			
2.2.	F2 Ax	kis Par	rameter							
	2.2.1. F1	Next				(displays ne	ext set	t of set	tings)	
	2.2.2. F2	Prior				(displays pl	rior se	t of set	ttings)	
	2 2 2 2 2 2 Setting Steps Note o	2.2.2.1. 2.2.2.1.1. 2.2.2.1.2. 2.2.2.1.3. 2.2.2.1.4. 2.2.2.1.6. Per Co Per Co	Display S Select Axis Increment degr Steps Per Display Pr Speed Uni Reset Disp oordinate	ettings s steps, inch ees, radian Coordinate ecision 0, .(it Settings s blay Defaul rand	nes, mill s, revolu e 0, .00, .0 second, ts (steps ge 1 to 5	(coordinate 1,2,3, imeters, cer itions (choo 000, .0000 (minute, hc s, 0, seconds	es, pre ntimet se one choos our (ch	ecision, ers, e one) noose c defau	speec one) ult	l units) 1
	Resolu	tion								
	The rat on the foll	tio of t Iowing	the actual o g variables	commande :	ed steps	per motor i	revolu	tion is	deper	ndent
	With e	ncode	er	2.2.2.4.2. E	Encoder	Enable (EE=	=7)			
	The mo (Examp	otor re ple:	esolution is If 2.2.2 4 x 100 = 4(s 4 times th .4.3. Encod 00	ne EL set er Line (ting count (EL)		İS	100	
	then th	ne mo	otor steps p	per motor re	evolutio	n	İS	<u>400)</u>		
	Withou	ut enc	oder 2.2.2.	4.2. Encode	er Enabl	e (EE=0)				
V.2	2	-	тмс мотс	DR CONTRO	OLLER 3	-6 AXES			42	

The Motor resolution is the motor step count times the MS setting (Example: If the motor is a 1.8 degree per step motor it has 200 step count

and 2.2.2.2.9 Micro Step Resolution (MS) is 256 200 x 256 = 51200 then the motor steps per revolution is <u>51200</u>)

The hand terminal can be configured to display and control each motor axis using

the following coordinates (at 2.2.2.1.2. Coordinates):

Steps, inches, millimeters, centimeters, degrees, radians, revolutions. The user needs to define the steps per coordinate for each axis. The hand terminal uses this setting to calculate move instructions and positional information

for each axis.

(Examples of how to calculate the value for 2.2.2.1.3. Steps Per Coordinate: example 1

- If 2.2.2.1.2 Coordinate is
 - is set for inches is 1

100

43 |

- and 2.2.2.4.2 Encoder Enable(EE) is and 2.2.2.4.3 Encoder lines (EE) is
- and The axis motor turns an 8 pitch screw (8 turns per inch) $4 \times 100 \times 8 = 3200$
- then 2.2.2.1.3. Steps Per Coordinate should be set for <u>3200</u>

example 2

- If 2.2.2.1.2. Coordinate is set for radians
- and 2.2.2.4.2. Encoder Enable(EE) is 0
- and the motor is a 1.8 degree per step motor it has 200 step count
- and 2.2.2.2.3. Micro Step Resolution is 128 there are 2π (6.283) radians per revolution 200 x 128 ÷ 6.283 = 4074.486 rounded to whole number is =4074
- then 2.2.2.1.3. Steps Per Coordinate should be set for <u>4074)</u>

Speed

The following factors have an effect on the speed of axis movement:

- 2.2.2.7. Initial Velocity (steps/sec) (VI)
- 2.2.2.5. Acceleration rate (steps/sec²) (A)
- 2.2.2.5. Maximum Velocity (steps/sec) (VM)
- 2.2.2.2.5. Deceleration rate (steps/sec²) (D)

The step units are either motor/micro step counts, when EE=0, or encoder step counts when EE=1. When the user changes the state of EE for a given controller that controller automatically changes the 4 speed factors to match the step size difference. This change is internally controlled in the IMS controllers.

(Example: An axis has the following settings : EE=0 TMC MOTOR CONTROLLER 3-6 AXES MS=256 VI=1000 A=1000000 VM=768000 D=1000000

When the user changes EE to EE=1 with an encoder line count of EL=100 The micro-step value (MS) will not change but the 4 speed values will change. In this example the

speed values will change by the ratio of 128(rounded down to an integer). This is based on the

original motor step count of 51200 (200motor steps x 256 micro-steps (ms=256)) divided by the

encoder step count of 400 (4 X encoder line count (EL=100)). The new settings will be:

EE=1 EL=100 MS=256 VI=7 A=7812 VM=6000 D=7812

This example will be reversed when EE is changed from EE=1 to EE=0)



Deceleration Rate (D) 40.000	if EE=0		91 to 61,035,160		
Deceleration Rate (D 1,000,000	if EE=1		91 to 1,525,878,997		
Initial Velocity (VI) if EE= Initial Velocity (VI) if EE=	= () =]	5,000 200,0	,000 00	1,000	40
Maximum Velocity (VM) if EE=O		5,000,000		
Maximum Velocity (VM 30720) if EE=1		200,000		
Micro-Step Resolution (100, 108, 125, 127, 128, 180 250 or 256	(MS)), 200,	1, 2, 4,	5, 8, 10, 16, 25, 32, 50, 64,		256
2.3.2.2.10. Motor Direction if + direction is clockwis	on variable is se or counter	a Har clockv	nd Terminal Variable. It o wise. This variable defau	detern ults to (nines CW. If

set for CCW the move size for all move except Move Absolute is multiplied by -1.

2.2.2.3. Speed Settings (Step 2.2.2.3.1. Select Axis 2.2.2.3.2. Jog Low Speed (steps 2.2.2.3.3. Jog High Speed (steps 2.2.2.3.4. Slew Velocity Minimur 2.2.2.3.5. Slew Velocity Maximu	s/Second) (per sec.) s per sec.) m (steps per se m (steps per s	(speed parame 1,2,3, ec.) ec.)	ters - VM)
Setting rang	e	/	default
Jog Low Speed (VM) if EE=0 Jog Low Speed (VM) if EE=1	5,000,000 200,000		7,680 307
Jog High Speed (VM) if EE=0 Jog High Speed (VM) if EE=1 30720	5,000,000 200,000		768,000
Slew Velocity Minimum (VM) <i>if EE=</i> Slew Velocity Minimum (VM) <i>if EE=</i>	:0 5,000,0 :1200,000	000	7,680 307
Slew Velocity Maximum (VM) if EE= 768,000	=0 5,000,0	000	
Slew Velocity Maximum (VM) if EE= 30720	=1200,000		



		\sim
\sim		/
×	•	~

(query error status in controllers for each axis with the following command:

§nPR_ER§ (command sent on com bus)

Once queried and recorded, the following command clears

the error flag:

§nER=0§ (command sent on com bus)

(Resets errors in motor controllers with the following

command:

§*ER=0§ (command sent on com bus)

2.2.3. F3 Save or Reset axis parameters

(user with password level 1 can save or delete axis settings)

2.2.3.1. F1 Single Axis (save or reset parameters on single axis)

Select Axis 1 2 3 4 ...

(user selects axis)

SAVE Current Settings

(user chooses to Save current settings)

Are you sure you want to save the changes to the operating parameters on axis \underline{n} ? Yes

(This window is displayed only when the SAVE Button has been selected) (The selected axis is displayed)

(Selecting YES will permanently save the current setting in 2.2.2.1. to 2.2.2.6.)

RESET Setting to Default Values

(user chooses to reset settings to defaults)

Are you sure you want to reset the operating parameters on axis $_n_$ to the default values? Yes

(This window is displayed only when the RESET Button has been selected) (The selected axis is displayed)

(Selecting YES will reset the setting in 2.2.2.1. to 2.2.2.6. to the Default values)

2.2.3.2. F2 All Axes all axes)

(save or reset parameters on

SAVE Current Settings

(user chooses to Save current settings)

Are you sure you want to save the changes to the operating parameters on ALL axes? Yes

TMC MOTOR CONTROLLER 3-6 AXES

(This window is displayed only when the SAVE Button has been selected) (Selecting YES will permanently save the current setting in 2.2.2.1. to 2.2.2.6.)

RESET Setting to Default Values

(user chooses to reset settings to defaults)

Are you sure you want to reset the operating parameters on ALL axes to the default values? Yes (This window is displayed only when the RESET Button has been selected) (Selecting YES will reset the setting in 2.2.2.1. to 2.2.2.6. to the Default values)

- 2.2.4.F4Return(return to higher menu)2.2.5.F5Stop All(stops all motors)2.3.F4Return(return to higher menu)2.4.F5Stop All(stops all motors)
- 3. F3 Custom Control (special motor control options) (all of the Custom Control functions require user with password level 2)

3.1. F1 Direct Command (NOT YET DEVELOPED) (Opens edit window for creating and sending direct commands and programs to the axes controllers.)

- 3.1.1. F4 Return (return to higher menu)
- 3.1.2. F5 Stop All (stops all motors)
- 3.2. F2 E-gearing (sets up multi axis "gear ratio" moves)

(This function sets up a primary axis and secondary axis or axes. E-gearing is only used in the single axis 1.1.2. Move Relative function.) When toggled on, the secondary axes are commanded to move when the primary drive moves. The secondary axes can be set to move at the same rate or in a fixed ratio of the primary axis. They can also be set to move in the same direction or the opposite direction of the primary axis.

Notes on E-gearing

E-gearing is a function that moves multiple axes at the same time at different rates and directions. The user defines one axis as the primary axis. Any of the other axes can be selected as secondary axis. The secondary axes move at a user selected ratio of the primary drive. An E-gear move starts and stops motor moves in the primary and all of the secondary axes at virtually the same time.

v.2 TMC MOTOR CONTROLLER 3-6 AXES

48 |

The user assigns the E-gearing parameters in the E-gearing set up table (3.3.1.). These parameters are primary axis, secondary axis/axes and the secondary gear factor and direction. The gear factor is a ratio of the rate and distance that the secondary axis will move compared to the primary axis movement. The direction selection determines if the secondary axis move is in the same or opposite direction of the primary axis. As an example if a secondary axis has been set up with a gear factor of 0.5, and a direction of opposite then that axis motor will rotate half as fast, half as many degrees and will rotate in the opposite direction as the primary axis.

The E-gearing is performed in the Single Axis Move Relative function (1.1.2.). E-gearing Operation

E-gearing is activated when all of the following conditions are met:

The Single axis Move relative (1.1.2.) window is opened

E-gearing is set ON in the E-gearing selection screen (3.2)

A primary and secondary Drive/s are selected in the E-gearing set up window (3.2.1.)

The drive selected in Single axis move (1.1.) is the E-gearing primary drive A display saying "E-gearing is ON" is displayed in the Move Relative (1.1.2.) window while E-gearing is activated.

The e-gearing function temporarily changes the following IMS controller settings of each secondary axis:

- A (acceleration rate)
- D (deceleration rate)
 - VI (initial velocity)
 - VM (maximum velocity)

Each E-gearing move also uses one or both of the following IMS commands for the primary and secondary axes moves:

MR (move relative in the positive direction)

-MR (move relative in the negative direction)

E-gearing calculations

Note :The terms *PDR*, *SDR*, and *SGM* are explained and used below for clarity. They are not commands.

For the Primary axis

Query the primary axis controller to determine the values for EE, EL and MS. If EE=1 the PDR(primary drive rate)=EL If EE=0 the *PDR*=MS x 50

Query the primary axis to determine the values for A, D, VI, and VM.

For each Secondary axis

Query the secondary axis to determine the values for EE, EL and MS. If EE=1 the SDR(secondary drive rate)=EL If EE=0 the *SDR*=MS x 50

v.2 TMC MOTOR CONTROLLER 3-6 AXES

Calculate the Secondary Gear Multiplier for each secondary axis (*SGM*) as follows: SGM(secondary gear multiplier)=Gear Factor* ÷ (PDR ÷ SDR) (*Use Gear Factor 3.2.1. for secondary axis being calculated.) Note: each secondary axis has it's own individual *SGM*

Copy the original A, D, VI and VM values to the IMS controller R1, R2, R3 and R4 registers.

Calculate the temporary A, D, VI, and VM values for each secondary axis. primary A x SGM =temporary secondary A primary D x SGM =temporary secondary D primary VI x SGM = temporary secondary VI primary VM x SGM = temporary secondary VM

Change the secondary drive's A, D, VI, and VM settings to the calculated temporary values.

The MR value is calculated and sent to the primary and secondary axes when the F2 Move+ (1.1.2.2.) or F3 Move- (1.1.2.3.) buttons are selected.

The calculation for the primary axis MR value is the same as described in 1.1.2.2. and 1.1.2.3..

The calculation for each of the secondary axis is:

Primary axis MR x SGM x direction sign* x motor direction**

*direction sign is +1 if direction for secondary axis is "same" (3.2.1)

direction sign is -1 if direction for secondary axis is "opposite" 3.2.1)

**if motor direction (2.2.2.2.10) is CW multiply by +1 if CCW multiply by -1 When exiting the single axis move relative window (1.1.2) change each secondary axis's A, D, VI and VM values back to the original saved values.

E-gearing ON* OFF* Primary axis = 2**

(*displays the status of the E-gearing function 3.2.2., ON or OFF ** displays Primary Drive 3.2.1.)

3.2.1. F1 Set up

(Sets up axes gearing)

Primary Drive Axis 2 (user selects axis)

Axes	state	gear fact	or direction	
	secondary*	0.65***	same	****
2	primary*	7**	same**	
3	no connection*			
4	no connection*			
5	secondary*	1.25***	opposite***	k
6	no connection*			

(*user selects axis E-gear state: primary, secondary or no connection ** Primary by default has a gear factor of 1 and direction is same (+1). ***user selects gear factor which is multiple of primary axis factor of 1 ****user selects rotational direction of the secondary axis to be the same (+1) or opposite (-1) of the primary axis)

3.2.2. F2 ON/OFF

(Toggles E-gearing ON and OFF)

Example of E-gearing move function, calculations and commands. For this example let us assume that the user has entered the values in the above E-gearing set up table (3.2.1.) For this example let us assumed that the following axis IMS controllers have the following settings:

Axis 2	EL MS A D	EE is is is is	is 1 100 256 8000 8000 100
A:	VM	is	4000
Axis I	EE EL MS A D VI VM	is is is is is	0 100 256 1000000 1000000 1000 25600
Axis 5	EL MS A D VI VM	EE is is is is is	is 1 100 256 8000 8000 100 4000

These setting are determined by querying each axis for each of the above values

Example

§2PR EE§ (query encoder values for axis 2)

For this example let us also assume that motor direction (2.2.2.2.10) setting are:

Axis 1 is CW

Axis 2 is CW

Axis 5 is CCW

Also in this example for the primary drive (axis 2) the let us assume that Steps Per Coordinate(2.2.2.1.3) is:

8000

From the home page of the hand terminal the user selects:

F1 Move Axis (1.)

then F1 Single axis (1.1.)

then under Select axis(1.1) axis 2 (which is the primary axis in this example)

then F2 Move relative (1.1.2.)

The hand terminal determines that::

A. the E-gearing function(3.2.2.) is toggled ON

B. the Primary Axis (3.2.1) is axis 2

C. one or more axis are assigned as secondary axes(2.3.1)

Since , A,B and C are true:

The hand terminal calculates the PDR (primary drive rate)

Since EE=1 And EL=100 PDR= 100

The hand terminal calculates the SDR (secondary drive rate) for each secondary axis (3.2.1)

For axis 1 Since EE=0 SDR= 256 (MS value) x 50= 12800For axis 5Since EE=1 SDR=100 (EL value)=100

The hand terminal calculate the SGM (secondary drive multiplier) for each secondary axis (3.2.1.)

for axis 1 SGM= 0.65 (gear factor) ÷ {100(PDR) ÷ 12800(SDR)] = <u>83.2</u> for axis 5 SGM=1.25 (gear factor) ÷ {100(PDR) ÷ 100(SDR)] = <u>1.25</u>

For all axes the A, D, VI, and VM values are stored in RI, R2, R3, and R4 The values are stored in all of the drives with:

§*R1=A§ (saves acceleration value to register 1)

§*R2=D§ (saves deceleration value to register 2)

§*R3=VI§ (saves initial velocity value to register 3)

§*R4=VM§ (saves maximum velocity value to register 4)

For each of secondary drive the temporary A, D, VI and VM values are calculated and loaded on their IMS controllers

For axis 1:

Since SGM=83.2 the axis 1 temporary A is 83.2 x 8000 = <u>66560</u>0

the primary A =8000

TMC MOTOR CONTROLLER 3-6 AXES

send 1)	§1A=665600§	(sets temporary	acceleratio	on to secondary drive
the primary D= send	= 8000 the §1D=65600§ (set	axis 1 temporary D s temporary decel) is 83.2 x 8 eration to s	000 = <u>665600</u> secondary drive 1)
the primary VI: send	=100 the §1VI=8320§ (set	axis 1 temporary V s temporary initial	l is 83.2 x 1 velocity to	00 = <u>8320</u> secondary drive 1)
the primary VN send secondary driv	∕l=4000 §1VM=33280§ e 1)	the axis 1 tempo (sets temporary	orary VM is maximum	83.2 x 4000 = <u>332800</u> velocity to
For axis 5:				
the primary A = send	=8000 §5A=10000§ (set	Since SGM=1.25 the axis 5 temporary accele	orary A is 1. eration to s	25 x 8000 = <u>10000</u> econdary drive 5)
the primary D= send	= 8000 the §5D=10000§(set	axis 5 temporary [s temporary decel) is 1.25 x 8 eration to s	000 = <u>10000</u> secondary drive 5)
the primary VI: send	=100 the §5VI=125§ (set	axis 5 temporary \ s temporary initial	/I is 1.25 x 10 velocity to	00 = <u>125</u> secondary drive 5)
the primary VN send secondary driv	Л=4000 §5VM=5000§ е 5)	the axis 5 tempo (sets temporary	orary VM is maximum	1.25 x 4000 = <u>5000</u> velocity to
From the ha F1 Set the value of From the ha	and terminal the distance (1.1.2.1.) 7.50 (the increm and terminal the	e user selects: I For this example I nental units have b e user selects:	et us assur been set for	ne the user types in inches)
	F2 MOVe + (1.1.2.	.2.)		
The calculat	tions for the prin	nary drive move siz	ze:	
primary driv If 1.1.2.1. and 1.1.2.1. and 2.2.2.2 and the St and since <u>is 60000</u> *Note If F3 N	ve (axis 2) Target Distance Move + 2.10. Motor Direct ceps Per Coordir 7.50 x +1 x+1 x 10 Move- (1.1.2.3.) wa	(axis 2) tion for + (axis 2) nate(2.2.2.1.3) 0 x8000 = +60000 ns selected instead	is 7.5 is +1* is 80 00 <u>the</u> of F2 Move	0 set for CW (+1) 00 <u>e move size for axis 2</u> + this value would be
*Note If F3 N -1	Aove- (1.1.2.3.) wa	is selected instead	ot F2 Move	+ this value would b

secondary drive (axis 1) Since the primary move size is +60000 and the SDR (secondary drive rate) and 2.2.2.2.10. Motor Direction for + (axis1) and since 600000x +1 x 83.2 = +4992000 4992000

83.2 is set for CW(+1)is the move size for axis 1 is

secondary drive (axis 5) Since the primary move size is +60000 and the SDR (secondary drive rate) and 2.2.2.2.10. Motor Direction for + (axis1) and since 60000 x -1 x 1.25 = -75000

İS 1.25 set for CCW (-1) İS the move size for axis 5 is -

75000

Move the primary and each secondary axis using values from the calculating examples above:

On primary drive §2MR_60000§ and On 1st secondary drive §1MR_4992000§ and On 2nd secondary drive §5MR_-75000§

Monitor the primary and secondary axes one at a time to determine when the moves are completed

§nPR_MV§ (axes will return 1 while moving and 0 when complete)

When F4 Return (1.1.2.4.) is selected, reset and save the original A, D, VI and VM values as follows:

§*A= R1§ (returns acceleration from register 1) (returns deceleration from register 2) §*D=R2§ §*VI=R3§ (returns initial velocity from register 3) §*VM=R4§ (returns maximum velocity from register 4) §*S§ (save values) 3.2.3. F4 Return (return to higher menu)

3.2.4. F5 Stop All

(stops all motors)

4. F4 Status

information)

Status screen is toggled on and off when the @ key is pressed

Current Position Limit	Error]
Axis 1 526.0* mm**	CW***	0****
Axis 2 20.7* mm** -***	0****	
Axis 3 -47.9* deg.**	_***	86****
Axis 4 -2.0* mm** -***	0****	
Axis 5 526.9* mm**	_***	0****
Axis 6 39888*steps**	_***	0****

(*position is based on the Axis Query - Current Coordinate.

* precision is based on 2.2.2.1.4. Display precision

**Type of coordinate is based on 2.2.2.1.2. Coordinate

Limit is based on the Axis Query – CW Limit Switch and CCW Limit Switch *Error is based on the Axis Query – Error Messages)

4.1.1. F4 Return

4.1.2. F5 Stop All

(return to higher menu)

5. F5 Stop All

(stops all motors)

(stops all motors)